

# **VESSEL SYSTEMS MONITOR**

# 4 METERS IN 1

#### 1. DC Systems Monitor

voltage (up to 3 batteries), amperage, battery state of charge-amp hours remaining, time remaining, % charge, battery temperature, cycle count

2. AC Systems Monitor voltage, amperage, watts, frequency

3. Tank Monitor (up to 3 tanks) gasoline, diesel, water, waste

#### 4. Bilge Monitor bilge pump-active, cycle count, duration/hr, cycle/24 hr

#### Alarms—high and low

DC-alarms for all values AC-alarms for voltage, amperage, and frequency Tank-high and low level alarms for fuel, water and waste Bilge-alarms for cycles, duration/hr

Display—three intuitive modes multi-line text to monitor all systems at a glance, icons for simple visual status, or large font that can be read from a distance

- Mounting—versatile case design offers three mounting options
- Customization—programmable legends and adjustable alarm functions can be customized

**BLUE SEA SYSTEMS ULTRASONIC** TANK SENDERS AVAILABLE

1810 used for diesel, water or waste (32" tank depth)





### **Replace these 4 meters with the VSM 422**





Part Number 1800 Vessel Systems Monitor





#### **DC** Specifications

Nominal System Voltage	12 or 24 Volts
Operating Voltage	8.5-33.0 Volts
Minimum Current Draw	35mA@12 Volts, backlight off
	18.8mA@24 Volts, backlight off
Voltage Accuracy	+/- 0.5%
Current Range	0–500 Amperes
Current Accuracy	+/- 1.0%


#### AC Specifications

Nominal System Voltage	120 Volts@60 Hz, North America
	230 Volts@50 Hz, Typical of Europe
Operating Voltage	0-300 Volts
Voltage Accuracy (RMS)	+/- 0.5%
Current Range	0-150 Amperes
Current Accuracy (RMS)	+/- 2.0%
Frequency	40–90 Hz

#### Regulatory

 $\mathsf{C}\,\mathsf{E}$  Marked for E60945 electro-magnetic interference

IP67–VSM 422 Surface Mount Gasket creates a waterproof seal on unit face–temporary immersion for 30 minutes.




#### Tank Senders Supported:


10 - 180  $\Omega$  VDO-Typical of Europe 240 - 33  $\Omega$  Teleflex-North America Blue Sea Systems Ultrasonic Tank Senders (sold separately) • for diesel, water, or waste - PN 1810 (32" tank depth) • for gasoline - PN 1811 (24" tank depth)


Specifications subject to change. See www.bluesea.com for additional information and specifications.

6847 Rev.002


## **VESSEL SYSTEMS MONITOR**







Included in Retail Packaging: head unit, surface mount bezel, surface mount gasket, DC Current Shunt - PN 8255, AC Current Transformer - PN 8256, Battery Temperature Sensor - PN 1820,



## BLUE SEA

425 Sequoia Drive Bellingham, WA 98226 USA 800-222-7617 (USA and Canada) Phone: 360-738-8230 Fax: 360-734-4195 www.bluesea.com