BLUE SEA SYSTEMS® Instructions

WeatherDeck® Waterproof Fuse Panels

PN 4302 / PN 4304 / PN 4306 / PN 4308

Designed for open-cockpit and flybridge applications

- Includes 15A, ATO®/ATC® Fuse installed in each position
- Bicolored LEDs illuminate circuit labels to quickly identify OFF (Red), ON (Green), or Blown (No color) circuits
- Backlighting is compatible with DeckHand Dimmers
- Independent label backlighting allows switching and dimming
- · Integrated switch guards reduce the risk of accidental switching
- Panels can be mounted in four different orientations
- Panel front rated waterproof IP67 when properly mounted with the watertight mounting gasket
- UV stabilized weather-resistant faceplate snaps on and off providing access to components and concealing mounting screws
- Square Format Label Set 4215 included

Installation

▲ CAUTION ▲

CAUTION symbol refers to a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.


\Lambda WARNING \Lambda

WARNING symbol refers to a potentially hazardous situation which, if not avoided, could result in death or serious injury.

- If you are not knowledgeable about electrical systems, consult an electrical professional.
- If the panel front is to be exposed to water, it must be properly sealed to the surface. The included gasket must be in place and the panel screwed down securely.
- Panel switches are not ignition proof—the panel must NOT be installed in an explosive environment such as a gasoline engine room or battery compartment.


A WARNING A

1. Before beginning electrical installation, disconnect all AC and DC power sources.




\land WARNING Å

2. Select mounting location and panel orientation away from flammable areas. Panel can be mounted in any of the four orientations shown below.



3. Cut opening with template provided.



GUARANTEE: Blue Sea Systems stands behind its products for as long as you own them. Find detailed information at www.bluesea.com/about. For customer service, call 800-222-7617.

12V DC

Blue Sea Systems Inc. 425 Sequoia Drive Bellingham, WA 98226 USA p 360.738.8230 f 360.734.4195 conductor@bluesea.com www.bluesea.com 6443 Rev.005

Specifications

Maximum Operating Voltage Maximum Operating Amperage Backlight Operating Current (Amperage) Panel Cumulative Rating

Switch Rating Backlighting Voltage Fuse Rating Material: Cover Panel 30A (PN 4302) 60A (PN 4304) 90A (PN 4306) 100A (PN 4308) 15A Maximum 12V DC Nominal 15A installed, others available UV Resistant Thermoplastic UL-V0 Flame Resistant Thermoplastic

15A @ 12V DC (per circuit)

10mA/Illuminated Circuit

Regulatory

Waterproof IP67—Protected against immersion up to 1 meter for 30 minutes


PN	Positions	Voltage	Width in (mm)	Height in (mm)	Depth in (mm)	Width Mounting Centers in (mm)	Height Mounting Centers in (mm)
4302	2	12V DC	3.88 (98.55)	2.60 (66.04)	2.50 (63.50)	3.31 (84.07)	2.04 (51.82)
4304	4	12V DC	3.88 (98.55)	4.30 (109.22)	2.50 (63.50)	3.31 (84.07)	3.74 (95.00)
4306	6	12V DC	3.88 (98.55)	6.00 (152.40)	2.50 (63.50)	3.31 (84.07)	5.44 (138.18)
4308	8	12V DC	3.88 (98.55)	7.70 (195.58)	2.50 (63.50)	3.31 (84.07)	7.14 (181.36)

Installation (continued)


4. To remove cover, apply heal of hand to label area and pull back on the cover edge.



Apply 12V DC label, and circuit labels. Remove fuse seal and check that appropriately rated fuses are installed for each device.



5. Securely tighten toggle switch boots. Mount panel in cutout with provided gaskets and screws. Insert fuse seal over fuses, ensure 2 seal ribs are pressed in the panel. Reattach the cover.



Application Example

6. Make connections as per diagram at right.

